



สีโปว ดุลลักซ์ อะคริลิกฟิลเลอร์ เป็นสีโปวขาว ที่ทำจากอะคริลิคอิมัลชัน มีเนื้อสีมากเป็นพิเศษ เพื่อการยัดเกาะ และการอุดโปวรอยแตกกว้างไม่เกิน 1 มิลลิเมตร และซ่อมแซมผนังที่มีรูลงให้เรียบ เหมาะสำหรับอุดโปวรอยแตกกว้างบนพื้นผิวไม้และปูน เพื่อให้แลดูเรียบก่อนทาสี

- ให้การยัดเกาะดีเยี่ยม
- อุดรอยแตกกว้าง
- ไม่ผสมสารตะกั่ว และปรอท

ข้อมูลทางเทคนิคและคุณสมบัติของฟิล์มสี

ประเภทสี	สีโปวอะคริลิก
ลักษณะฟิล์มสี	ด้าน
ขนาดบรรจุ	1/4 และ 1 ยูเอสแกลลอน
เฉดสี	ขาว
เนื้อสีโดยปริมาตร	48-52%
ระยะเวลาแห้งสัมผัส	30 นาที ที่ความหนา 0 – 5 มม. การแห้งจะแปรเปลี่ยนตามความหนาที่ใช้โปว
ระยะเวลาทาทับ	โดยปกติจะปล่อยให้แห้งข้ามคืนก่อนทำการขัดให้เรียบ
การครอบคลุมพื้นที่ตามทฤษฎี	10 – 15 ตร.ม. / เทียว / ยูเอสแกลลอน (ที่ความหนาฟิล์มสีเมื่อเปียก 5 มิลลิเมตร)
*พื้นที่ครอบคลุมเป็นค่าทางทฤษฎี อาจแตกต่างจากการใช้งานจริงไม่เกิน 20%	

ระบบการทาสี

ก่อนการทาสีทุกครั้ง พื้นผิวจะต้องแห้ง สะอาด ปราศจากฝุ่นละออง เศษซีเมนต์ คราบไขมัน และสิ่งสกปรกต่างๆ หากมีรอยแตกกว้างไม่เกิน 1 มม. ให้ซ่อมด้วยสีโปว ดุลลักซ์ อะคริลิก ฟิลเลอร์ 1040 ขัดแต่งให้เรียบ หากต้องการเพิ่มความเนียนเรียบให้กับพื้นผิว หรือปรับซ่อมผิวคอนกรีตที่มีปัญหา ให้ฉาบทั้งผนังด้วย ดุลลักซ์ สมูทโอเวอร์ แล้วขัดแต่งให้เรียบและให้แน่ใจว่าผนังไม่มีรอยรั่วซึมของน้ำ เพื่อป้องกันฟิล์มสีโปงพองภายหลัง

ขั้นที่ 1 การเตรียมพื้นผิว

- พื้นผิวปูนใหม่ไม่เคยทาสี หรือทาสีแล้วสียังอยู่ในสภาพดี ทั้งพื้นผิวปูนแห้งสนิทอย่างน้อย 1 เดือน หลังจากฉาบปูน มีความชื้น ไม่เกิน 14 % ควรขัดล้างสีเดิมที่เสื่อมสภาพออกให้หมด บริเวณที่มีเชื้อรา หรือตะไคร่น้ำ ให้ล้างด้วยน้ำสะอาด ทั้งให้แห้งแล้วทาด้วยน้ำยากำจัดเชื้อราและตะไคร่น้ำ ดุลลักซ์ เวเธอร์ชีลด์ ไมลด์วาช โดยทาทั้งไว้ข้ามคืน จากนั้นขัดล้างออกด้วยน้ำ ให้สะอาด ทั้งไว้ให้แห้งสนิท
- พื้นผิวปูนเก่าที่เสื่อมสภาพ การขัด หรือการขจัดฟิล์มสีด้วยความร้อน อาจทำให้เกิดฝุ่นและ/หรือฟุ้งที่เป็นอันตราย หากทำได้ควรใช้วิธีการขัดด้วยแปรงและน้ำแทน ควรปฏิบัติงานในที่มียกอากาศถ่ายเทสะดวก สวมอุปกรณ์ป้องกันส่วนบุคคลที่เหมาะสม

ขั้นที่ 2 การทาสีรองพื้น

- พื้นผิวปูนใหม่ไม่เคยทาสี หรือทาสีแล้วสียังอยู่ในสภาพดี ทาสีรองพื้นปูนอะคริลิก ดุลลักซ์ เวเธอร์ชีลด์ ซูเปอร์ ไพร์เมอร์ จำนวน 1 เทียว ทั้งให้แห้งอย่างน้อย 2 ชั่วโมง ก่อนทาสีทับหน้า
- พื้นผิวปูนเก่าที่เสื่อมสภาพ เป็นฝุ่นขอลึกหรือไม้สังเคราะห์ ทาน้ำยารองพื้นปูนเก่า เพื่อเสริมการยึดเกาะ ดุลลักซ์ มาซิล จำนวน 1 เทียว ทั้งให้แห้งอย่างน้อย 10-12 ชั่วโมง ก่อนทาสีทับหน้า
- พื้นผิวปูนใหม่และปูนเก่า ที่มีความชื้นสูงแต่ไม่เกิน 25% ทาสีรองพื้นปูนอุดประสิทธิภาพสูง ดุลลักซ์ เวเธอร์ชีลด์ พาวเวอร์พลัส ไพร์เมอร์ 1 เทียว ทั้งให้แห้งอย่างน้อย 2 ชั่วโมง ก่อนทาสีทับหน้า

ขั้นที่ 3 การทาสีทับหน้า

ทาสีทับหน้าด้วย สีน้ำสำหรับทาภายนอก และ/หรือ สีน้ำสำหรับทาภายในตระกูล ดุลลักซ์ อย่างน้อย 2 เทียว โดยทิ้งระยะห่างระหว่างสีที่ทาชั้นแรกและชั้นถัดไป ประมาณ 30 นาที – 2 ชั่วโมง



ISO 9001 QMS03026/630
ISO 14001 EMS05021/198
OHSAS 18001 OHSAS04016/079
TIS 18001 OHS01013/028

CMANZ/IV-2016/113/70



Dulux Acrylic Wall Filler is heavy pigmented white acrylic emulsion filler with good adhesion and filling properties to repair wall cracks max. 1 mm. and/or other imperfections. It is recommended for most wood and masonry surfaces where there are cracks and other imperfections that need to be made good prior to painting.

- Good adhesion and filling
- Excellent in repairing wall cracks
- Contains no added and no added mercury

Technical Information & Paint Film Properties

Type of Paint	Acrylic Wall Filler
Finish	Matt
Pack size	1/4 and 1 U.S. Gallons
Colour Offer	White
Volume Solids	48-52%
Touch Dry	30 Minutes at 0 – 5 mm. film thickness
Recoat Dry	Normally required overnight drying before sanding.
Theoretical Coverage	10-15 Square Metre per Coat per U.S.Gallon

*Coverage is theoretical value and may differ from real application +20%

Application System

Surfaces must be dry, clean, and free from dirt, loose materials, and grease. If there is a crack of no more than 1 mm, repair with Dulux Acrylic Filler 1040 as surfaces must be sealed to prevent water leaking to the paint films which would causes film bubble and peeling problems. If the smoothness is needed, apply the wall with Dulux Smoothover acrylic skim-coat.

Step 1: Surface Preparation

- *New masonry or previously painted in good condition* : Leave new masonry to be fully cured at least 1 month. Moisture not over 14%. Allow surfaces to dry out.
- *Previously painted or powdery surfaces* : Rub down and treat any area affected by fungus and algae with Dulux Weathershield Mouldwash and leave it overnight to dry. Then rinse off with water and allow the wall to dry.
Treatments such as sanding, burning off etc of paint films may generate hazardous dust and/or fumes. Wet sanding/flatting should be used wherever possible. Work in well ventilated areas. Use suitable personal protection equipment.

Step 2: Priming

- *New masonry or previously painted in good condition* : Apply 1 coat of Dulux Weathershield SuperPrimer. Allow at least 2 hours drying before applying top coat
- *Previously painted, powdery surfaces, fiber-cement or skim coat surfaces:* : Apply a thin coat of Dulux Maseal for better adhesion. Allow at least 10-12 hours drying
- *New or previously painted with high moisture surface (max. 25%)* : Apply 1 coat of Dulux Weathershield Powerplus Primer. Allow at least 2 hours drying prior to applying top coat

Step 3: Topcoat

- : Apply 2 coats of any Dulux Interior or Exterior Paints. Allow at least 30 minutes - 2 hours drying between coats. Diluted with clean water only.



CM AZN JV-2016.1.13.70



ISO 9001 QMS03026/630
ISO 14001 EMS05021/198
OHSAS 18001 OHSAS04016/079
TIS 18001 OHS01013/028