



สีรองพื้นเสริม ดุลลักซ์ สปีดอันเดอร์โคท

สีรองพื้นเสริมคุณภาพเยี่ยม



สีรองพื้นเสริม ดุลลักซ์ สปีดอันเดอร์โคท เป็นผลิตภัณฑ์สีน้ำมันที่ทำจากเรซินสังเคราะห์ประเภทอัลคิด ทาง่าย ให้เนื้อสีหนามาก และแห้งเร็ว ไม่ผสมสารปรอทและตะกั่ว เหมาะสำหรับทาทับสีรองพื้นชั้นแรกบนพื้นผิวชนิดต่างๆ เพื่อเสริมการยึดเกาะของฟิล์มสีทับหน้า

- รองพื้นเสริมอนุภาคประสงค์ เพื่อเสริมความเรียบเนียน
- ไม่ผสมสารตะกั่ว และสารปรอท

ข้อมูลทางเทคนิคและคุณสมบัติของฟิล์มสี

ประเภทสี	สีรองพื้น
ลักษณะฟิล์มสี	กึ่งเงา
ขนาดบรรจุ	1 และ 5 ยูเอสแกลลอน
เฉดสี	สีขาว
เนื้อสีโดยปริมาตร	ประมาณ 50 - 60%
ระยะเวลาแห้งสัมผัส	30 นาที
ระยะเวลาทาทับ	6-8 ชั่วโมง
การควบคุมพื้นที่ตามทฤษฎี	40 - 50 ตร.ม./เที่ยว/แกลลอน
*พื้นที่ควบคุมเป็นค่าทางทฤษฎี อาจแตกต่างจากการใช้งานจริงไม่เกิน 20%	

วิธีการใช้งาน

เครื่องมือ และอุปกรณ์ในการใช้งาน	แปรง
การผสมก่อนใช้งาน	สามารถใช้ได้ทันที หรือเติมน้ำยาผสมสีน้ำมันดุลลักซ์ (T850-411) 1 ส่วน ต่อสี 10 ส่วน (ไม่เกิน 10%)
การทำความสะอาด	ล้างทำความสะอาดอุปกรณ์ด้วย น้ำยาผสมสีน้ำมันดุลลักซ์ (T850-411) ทันทีหลังการใช้งาน

ระบบการทาสี

พื้นผิวที่จะทาต้องแห้ง สะอาด ปราศจากคราบไขมันและฝุ่นผง ควรขัดลอกพื้นผิวเก่าด้วยกระดาษทรายก่อนทาทับด้วยสีรองพื้น สำหรับพื้นผิวอลูมิเนียม สแตนเลส สังกะสี ควรทำความสะอาดให้ปราศจากคราบไขมัน หรือให้ปฏิบัติตามคำแนะนำของผู้ผลิต

การเตรียมพื้นผิว สำหรับพื้นผิวไม้

- พื้นผิวไม้ใหม่
- พื้นผิวไม้เก่า

ในกรณีนี้สีเดิมยังอยู่ในสภาพดี
ในกรณีนี้สีเดิมเสื่อมสภาพ

- สำหรับงานไม้ทุกประเภท

ขัดผิวให้เรียบ แล้วทำความสะอาดพื้นผิวให้ปราศจากคราบไขมันและฝุ่นผง

ลูบผิวให้หยาบด้วยกระดาษทรายเพื่อเสริมการยึดเกาะ แล้วทำความสะอาดผิวให้ปราศจากคราบไขมันและฝุ่นผง ให้ขัดลอกสีเดิมที่เสื่อมสภาพออก แล้วทำความสะอาดผิวให้ปราศจากคราบไขมันและฝุ่นผง ถ้ามีรอยแตกหรือรู ให้อุดด้วยสีโป้วดุลลักซ์ อะคริลิก ฟิลเลอร์ 1040 และเพื่อการป้องกันที่สมบูรณ์แบบ หากมีหัวตะปู ให้แถมสีรองพื้นกันสนิมตามชนิดหัวตะปู

การทาสีรองพื้น

ทาสีรองพื้นไม้ดุลลักซ์ อลูมิเนียม 1 เที่ยว ด้วยแปรง โดยใช้วิธีทาแบบไขว้ไปมา เพื่อให้สีรองพื้นซึมเข้าไปในเนื้อไม้ ทั้งระยะเวลาให้แห้งสนิทหรือประมาณ 8 - 10 ชั่วโมง ก่อนทาสีรองพื้นเสริมหรือสีทับหน้า

การทาสีรองพื้นเสริม

ทาสีรองพื้นเสริมดุลลักซ์ สปีดอันเดอร์โคท ด้วยแปรง ลูกกลิ้งหรือเครื่องพ่น เพื่อเสริมความเรียบเนียนให้กับพื้นผิว ทั้งระยะเวลาให้แห้งสนิทหรือประมาณ 6 - 8 ชั่วโมง ก่อนทาสีทับหน้า

การทาสีทับหน้า

ทาสีทับหน้าด้วย สีน้ำมันเคลือบเงา ดุลลักซ์ กลอส ฟินิช หรือ ดุลลักซ์ ซิดคิวิต อย่างน้อย 2 เที่ยว ด้วยแปรงทาสี ลูกกลิ้งขนเรียบหรือสเปร์รี่ โดยใช้เวลาให้ชั้นแรกแห้งสนิทก่อนทาทับหน้าชั้นถัดไปประมาณ 8 - 10 ชั่วโมง



CM.AZNI-F-2016.1.33.44



ISO 9001 QMS03026/630
ISO 14001 EMS05021/198
OHSAS 18001 OHSAS04016/079
TIS 18001 OHS01013/028



Dulux Speed Undercoat

Primer for exterior and interior



Dulux Speed Undercoat is oil modified alkyd based paint. It has excellent flow and build. Contains no added mercury. A quick drying general purpose undercoat for use over correctly primed or previously painted wooden, metal and masonry surfaces.

- General purpose undercoat to enhance smooth finish of top coat
- Contains no added mercury

Technical Information & Paint Film Properties

Type of Paint	Primer
Finish	Semi-gloss
Pack size	1 and 5 U.S. Gallons
Colour Offer	White
Volume Solids	50 - 60%
Touch Dry	30 minutes
Recoat Dry	6 - 8 hour
Theoretical Coverage	40 – 50 Sq.m./coat/gallon

*Coverage is theoretical value and may differ from real application +-20%

Application

Application Method	Brush
Mixing Ratio	Ready to use. Can be thinned with 1 part of Dulux Quick Cut Solvent (T850-411) to 10 parts of the product (10%)
Cleaning Up	Clean all equipment with Dulux Quick Cut Solvent (T850-411) immediately after used

Application System

Surface generally must be clean, dry and free from defective or poorly adhering material, dirt, grease, wax etc. Previously painted surfaces should be thoroughly rubbed down using a suitable abrasive paper and then dusted off. For optimum performance new galvanized, aluminum and stainless steel surfaces should be cleaned and degreased. Then follow the instruction of manufacturer.

Surface Preparation : Wooden Surface

- *New wood* Rub down until smooth surfaces. Then clean surface to remove all grease and dirt.
- *Old wood* Rub down with abrasive paper for good adhesion of new paint. Then clean surface to remove all grease and dirt.
- *Good condition previously painted masonry* Thoroughly rub down till old paint and rust totally removed. Then clean surface to remove all grease and dirt.
- *Defective condition previously painted masonry*

Priming Apply 1 coat of Dulux Aluminium Wood Primer. It is best applied by brush with a crisscross motion using considerable pressure to promote paint penetration. Allow 8 - 10 hours drying prior applying top coat.

Priming (Enhance smooth finish) Apply 1 coat of Dulux Speed Undercoat with brush, roller and spray to enhance smooth finish. Allow 6 - 8 hours drying prior applying top coat.

Coating Apply at least 2 coats of Dulux Gloss Finish or Dulux Silkwood with brush, short hair roller or spray. Allow at least 8 - 10 hours drying between coat.



CMAZN1-201613344



ISO 9001 QMS03026/630
ISO 14001 EMS05021/198
OHSAS 18001 OHSAS04016/079
TIS 18001 OHS01013/028

The information in this datasheet is given to the best of our knowledge based on laboratory testing and for use recommendation. As the product is often used under conditions beyond our control, the company cannot guarantee anything only the quality of the product.

AkzoNobel Paints (Thailand) Ltd. (Former ICI Paints (Thailand) Ltd.) 34/5 Moo 1 Chaeng Watana Road, Klongkue, Pakkred Nonthaburi 11120
Customer Service : Telephone (662) 572-8888 Fax (662) 572-8889 www.dulux.co.th, www.facebook.com/duluxthailand